



SECURITY SYSTEM QUICK REFERENCE GUIDE

TO ARM ENTIRE SYSTEM – BOTH INTERIOR AND PERIMETER

- Close all windows and doors (the green READY light will turn ON)
- Press and hold  (Away) for 2 seconds (the keypad will beep rapidly 5 times and the red Armed light will turn ON)
- Exit premises before the delay time expires
- If the green READY light is not lit, re-check the door(s) listed.
- Then BYPASS if necessary (see below)



TO DISARM SYSTEM WHEN YOU RETURN

- When you enter through the door, the keypad will emit a steady warning tone
- Enter your 4-digit Master Code or User Code (the armed light will turn OFF)
- If you make an error, press  and enter the 4-digit code again

TO ARM PERIMETER OF BUILDING AND STILL MOVE FREELY INSIDE

- Press and hold  (Stay) for 2 seconds




BYPASS - TO ARM SYSTEM WITH DOOR OR WINDOW OPEN

- Press   while disarmed
- The Bypass light will flash
- Enter the 2-digit zone number to be bypassed
- To exit the Bypass function press

TO SILENCE ALARM

- Enter your 4-digit Master Code or User Code

WHEN TROUBLE LIGHT COMES ON

- Press  
- All keypads will describe the Trouble Condition
- If LOSS OF CLOCK appears on the display, the time and date needs to be reset (see below)
- If SERVICE REQUIRED appears on the display, press the  button, if LOW BATTERY appears, the battery needs to be replaced (see below)
- If the display is BLANK or for all other trouble conditions, contact HunTel Security at 402-462-6363 or toll free at 866-854-6363

SECURITY SYSTEM QUICK REFERENCE GUIDE

TO SET TIME AND DATE

- Press ***** **6** and enter the 4-digit Master Code
- 1 long beep indicates an error, press **#** and enter the Master Code again
- After 4 short beeps, press **1** then 10 digits, 2 each for the hour, minutes, month, day and year (HH:MM MM/DD/YY)
 - ❖ Use a 24-hour clock (e.g. 8:30pm = 20:30)
 - ❖ Use 2 digits each to indicate the month and day (e.g. March 8 = 03 08)
 - ❖ Only enter the last 2 digits of any given year (e.g. 2016 = 16)

TO REPLACE SYSTEM BATTERY

- Call HunTel Security at 402.492.6363
- Have the Security System put on TEST, so the battery can be replaced
- The battery is located in the Main Security Control Box, not the KEY PAD
- Replace only with a like battery 12V (volt) 7AH (amp hours), these batteries are carried in your store
- Connect the RED wire to the RED terminal and the BLACK wire to the BLACK terminal
- The TROUBLE CONDITION (on key pad) can take up to an hour to clear, depending on the battery start level

TO ENABLE DOOR CHIME FEATURE

- Press and hold **🔔** (Door Chime) for 2 seconds
- 3 beeps = ON; 1 long beep = OFF

TO SOUND AN ALARM MANUALLY

- Press and hold **🔥** (Fire) or **⚠️** (Emergency) or **🚒** (Panic) for 2 seconds

FOR MORE INFORMATION

- Visit www.dsc.com to download the complete user manual
- Call HunTel Security at 402.492.6363 or toll free at 866.854.6363